AVSOUPMVAA

SOUP MAKER

PACKAGE CONTENTS

In the box

- Lid
- Metal Jug
- Power Lead
- Instruction Manual

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Check the voltage on the rating plate corresponds with your supply voltage before plugging the appliance in.
2. This appliance should not be used by anyone (including children) with reduced physical, sensory or mental capabilities or by those lacking in experience or knowledge; they should always be supervised by someone who is responsible for their safety and well-being.
3. Children should be supervised to ensure they do not play with the appliance.
4. Do not operate the appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person.
5. Use this appliance only for its intended use as detailed in this manual.
6. Do not leave the appliance unattended whilst in use.
7. Always keep hands, fingers, loose clothing and other items away from the rotating blades.
8. Do not use the appliance if the rotating blades are damaged.
9. Do not use the appliance with an empty jug.
10. Do not use the appliance without the lid being securely fixed in place.
11. Do not immerse the appliance in water or any other liquids.
12. Do not attempt to move the appliance whilst it is in use.
13. Do not allow water to get onto the electrical connections. If the connections do get wet, unplug from the socket immediately and dry thoroughly before use.
14. This appliance contains no user serviceable parts. Repairs should only be carried out by a qualified service engineer.
15. The appliance should be unplugged from the power supply after use and whilst any maintenance, such as cleaning, is carried out.
16. Always use this appliance on a stable, heat resistant surface.
17. Always ensure there is sufficient ventilation around the appliance when in use.
18. The jug body may become hot during use, always utilise the handle provided.
19. This appliance is not suitable for use outdoors.
20. This appliance is intended for household use only.
21. Do not touch the power cord or appliance with wet hands.
22. Do not use this appliance near water or in a damp environment.
23. Do not use the appliance where children can easily touch it and do not allow children to use the unit by themselves.
24. Do not plug the appliance into a socket where several other appliances are plugged in.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

Any servicing should be performed by an authorized service representative.

ELECTRIC REQUIREMENTS

Voltage: 240V.A.C Hertz: 50Hz Heating Power: 800W
Motor Power: 250W Speed: 11000-22000 RPM

PREPARATION

- Remove the Soup Maker from the box
- Remove packaging from the product
- Place packaging inside the box and either store or dispose of safely

Important

Do not connect your soup maker to the mains supply until you have added your chosen ingredients.
Please do not switch on the soup maker when empty.

How to use

The soup maker has two pre-programmed cooking settings for making smooth pureed or chunky soup. The built in chopping blades also allow the appliance to be used as a blender to make juices, purees or dips.

The soup maker is fitted with an overflow sensor for safe use during the soup making process.

Before using the soup maker for the first time, wipe down the jug and lid with a damp cloth and mild detergent.

Do not immerse the unit, jug or lid in water or any other liquids.

Caution: Handle the lid with care at all times as the chopping blades are very sharp.

Place the base unit of the soup maker on a heat resistant, stable surface, add soup ingredients and position the lid on the jug unit, aligning the connections on the top of the jug. The lid should fit securely into place on top of the base unit.
Connect your soup maker to the power supply.

Application

Making Soup

Chop all ingredients into 2-3cm cubes and add to the soup maker jug.

Caution: It is not recommended to use uncooked meats in your soup maker – you should pre-cook any meat or fish to be used.

Do not add any frozen ingredients to the soup maker; all ingredients must be at room temperature.
Add your preferred liquid or stock to the jug, making sure that the total volume of ingredients is at least 1000ml (min. level) but no more than 1300ml (max. level).

If the volume is more than the max. level, the overfill sensor will sound an alarm and your soup maker will fail to operate to prevent the overflow of hot liquid during operation.

After adding the ingredients, fit the lid on the soup maker jug unit, aligning the connections on the top of the jug. The lid should sit securely on top of the base unit.

When everything is positioned correctly, plug the soup maker into the mains power supply and the LEDs next to the 3 switches will flash. Press the ‘Smooth’ button to make pureed soup and the ‘chunky’ button to create chunky soup; the corresponding LED will illuminate.

Always make sure you allow the soup maker to cool sufficiently before making a second batch of soup.

Smooth Mode

When making smooth soup, the soup maker will automatically heat the ingredients and blend them to a pre-set programme. This process will take approximately 25-30 minutes.

Chunky Mode

When making chunky soup, the soup maker will automatically heat the ingredients to a pre-set programme. This process takes about 35 minutes. This programme does not have an automatic blend function. Once the soup is cooked, it may be necessary to blend the soup to the required consistency using the blend button.

Caution: The jug of the soup maker will get very hot during use; take care not to touch the jug or lid.
To stop the soup making process, lift the lid slightly using the handle. Replace the lid once the soup maker has stopped and disconnect from the mains power supply.

Caution: Always take care when removing the lid.

Once the programme has finished, your soup maker will sound an audible alarm and stop heating.
Your soup is now ready to serve.

Soup can be poured directly from the jug into a bowl but care should be taken when removing the lid from the jug as it may be very hot.

Blend / Clean Mode

The soup maker can also be used as a blender.
In this mode, the heating function will not operate, allowing ingredients to be blended to make juices, smoothies, purees and dips.

Simply set up the soup maker as previously described.
Chop all the ingredients into 2-3cm chunks and add to the soup maker jug.
Ensure the total volume of ingredients added is not more than 1300ml (max. level).

Do not attempt to blend any dry ingredients.

Press the ‘blend’ button continuously and the corresponding LED will flash. The unit will automatically stop blending after 60 continuous seconds; wait a few minutes and then press the ‘blend’ button again if further blending is required.

Do not use the blending mode for more than 1 minute without allowing it to cool sufficiently.

Always allow the unit to cool before the next use.

Cleaning and Maintenance

Do not clean the soup maker in a dishwasher.

Always disconnect the soup maker from the mains power supply before cleaning.

Do not immerse the soup maker in water or any other liquids.

Clean the outer surface of the soup maker base unit (jug) and lid (motor) with a soft, damp cloth.

To clean the inside of the jug rinse in clean water to remove any remaining soup or foodstuff. Wipe away any remaining food with a soft cloth and mild detergent before rinsing again.

Caution: The blades under the lid are not removable and are very sharp; extreme caution should be taken when cleaning the inside of the lid.

Use the soup maker's 'blend/clean' function to aid the removal of stubborn stains.

Simply assemble the soup maker as previously described and add 1300ml warm water with a small amount of mild detergent. Fit the lid and press the 'blend/clean' button continuously until any stains have been removed.

Do not use the blending mode for more than 20 seconds at a time.

Troubleshooting

Problem	**Solution**
The unit is not working and is bleeping	The soup maker has been over-filled. Remove liquid until it falls below the maximum level.
Ingredient pieces are still too large after the smooth cycle is complete	Pieces may have been too large initially – use the 'blend / clean' function after the cooking program
The ingredients are not cooked properly at the end of the cycle	Chop the ingredients into smaller pieces before adding to the soup maker
The 'blend/clean' mode is not working after 20 seconds of blending.	The program will automatically stop the blend function after 20 seconds of continuous operation. Wait for a few minutes and try again. Note: Always allow the unit to cool sufficiently after each blend operation.

Warranty

In the event of a problem with your item please contact support@avancer.com.au

This product is guaranteed against mechanical and electrical defects for a period of 1 year from the date of purchase.

This guarantee is only valid if the appliance is used solely for domestic purposes in accordance with the instructions and provided that it is not connected to an unsuitable electricity supply or dismantled or interfered with in any way or damaged through misuse. Under this guarantee we undertake to repair or replace free of charge any parts found to be defective. Reasonable proof of purchase must be provided.
Nothing in the guarantee or in the instructions relating to this product excludes, restricts or otherwise affects your statutory rights.

In line with our policy of continuous improvement, we reserve the right to modify this product, packaging and documentation specification without notice

According to the Waste Electrical and Electronic Equipment (WEEE) directive, WEEE should be separately collected and treated. The above symbol on the product or its packaging indicates that this product is not to be handled as normal household waste but is to be taken to a recycling collection point for electrical and electronic goods. By correctly disposing of this product you are contributing to the protection of the environment and to the health of your fellow human beings. Improper disposal endangers health and the environment. Further information about the recycling of the product may be obtained from your local council, refuse collection department or the store where you purchased the product.